

10G XFP 1550nm Single-Mode 40km Optical Transceiver XFP-10G55-40-xx



Features

- Supports 9.95Gb/s to 11.3Gb/s date rates
- ➤ Hot-pluggable XFP Footprint
- Maximum Link Length up to 40km
- Temperature-Stabilized EML transmitter
- Duplex LC Connector
- Power Dissipation <3.5W</p>
- ➤ Built-in Digital Diagnostic Functions
- Case Operating Temperature
- > Standard: 0°C to 70°C

Applications

- > 10GBASE-ER/EW 10G Ethernet
- > 1200-SM-LL-L 10G Fiber Channel
- SONET OC-192 IR-2
- > SDH STM S-64.2b
- ➤ SONET OC-192 IR-3
- > SDH STM S-64.3b
- ➤ ITU-T G.709

Description

The XFP-10G55-40-xx series single mode transceiver is small form factor pluggable module for duplex optical data communications such as 10GBASE-ER/EW defined by IEEE 802.3ae. It is with the XFP 30-pin connector to allow hot plug capability.

This module is designed for single mode fiber and operates at a nominal wavelength of 1550 nm. The transmitter section uses a 1550nm EML, which is class 1 laser compliant according to International Safety Standard IEC-60825. The receiver section uses an integrated InGaAs detector preamplifier (IDP) mounted in an optical header and a limiting post-amplifier IC.

Specifications

Table 1 - Absolute Maximum Ratings

Parameter	Symbol	Min	Тур	Max	Unit
Maximum Supply Voltage 1	V_{CC3}	-0.5		4.0	V
Maximum Supply Voltage 2	V_{CC5}	-0.5		6.0	V
Storage Temperature	T_{S}	-40		85	°C

Table 2 - Recommend operating condition

Parameter	Symbol	Min	Тур	Max	Unit
Case Operating Temperature	ТОР	0		70	°C
Supply Voltage 1	V_{CC3}	3.13	3.3	3.45	V
Supply Voltage 2	V_{CC5}	4.75	5	5.25	V

Table 3 - Electrical Characteristics

(TOP = -40 to 85°C, VCC5 = 4.75 to 5.25 Volts

Parameter	Symbol	Min	Тур	Max	Unit	Note	
Main Supply Voltage	V_{CC5}	4.75		5.25	V		
Supply Voltage #2	V_{CC3}	3.13		3.45	V		
Supply Current – Vcc5 supply	Icc5			370	mA		
Supply Current – Vcc3 supply	Icc3			500	mA		
Module total power	Р			3.5	W		
	Transmitter						
Input Differential Impedance **Note2	Rin		100		Ω	1	
Differential Data Input Swing	Vin,pp	120		820	mV		
Transmit Disable Voltage	V_D	2.0		V_{CC}	V		
Transmit Enable Voltage	$V_{\scriptscriptstyle EN}$	GND		GND+0.8	V		
Transmit Disable Assert Time				10	US		
Receiver							



Differential Data Output Swing	Vout,pp	340	650	850	mV	
Rise Time (20 – 80%) **Note3	tr			38	PS	2
Fall Time (20 – 80%) * Note3	tf			39	PS	2
LOS Fault	VLOS fault	Vcc – 0.5		VccHOST	V	3
LOS Normal	VLOS norm	GND		GND+0.5	V	3
Power Supply Rejection	PSR	See Note 4 below			4	

Note2: After internal AC coupling

Note3: Loss Of Signal is open collector to be pulled up with a 4.7k – 10k ohm resistor to 3.15 – 3.6V. Logic 0 indicates normal operation; logic 1 indicates no signal detected.

Note4: Per Section 2.7.1. in the XFP MSA Specification.

Table 4 - Optical Characteristics

Parameter	Symbol	Min	Тур	Max	Unit	Ref.
Transmitter						
Optical Modulation Amplitude	Р	-2.1			dBm	
Output Opt. Pwr: 9/125 SMF	Pout	0		+4	dBm	
Optical Wavelength	λ_c	1530		1565	nm	
Optical Extinction Ratio@10.3Gb/s	ER	8.2			dB	
Transmitter and Dispersion Penalty	TDP			2	dB	
Average Launch power of OFF transmitter	P_{OFF}			-30	dBm	
TX Jitter Generation (Peak-to-Peak)	Txj			0.1	UI	
TX Jitter Generation (RMS)	TXjRMS			0.01	UI	
	Re	ceiver				
Receiver Sensitivity @ 10.7Gb/s	Pmin			-16	dBm	
Maximum Input Power	Pmax	0			dBm	
Optical Center Wavelength	λ_{C}	1270	1550	1600	nm	
Receiver Reflectance	Rrx			-27	dB	



LOS De-Assert	LOSD		-18	dBm	
LOS Assert	LOSA	-30		dBm	
LOS Hysteresis		1		dB	

Table 5 - Pin Descriptions

PIN Logic		Symbol	Name/ Description	Note	
1	1 GND Modu		Module Ground	1	
2		VEE5	Optional –5.2 Power Supply – Not		
			required		
3	LVTTL-I	Mod-Desel	Module De-select; When held low allows		
			the module to ,		
			respond to 2-wire serial interface		
			commands		
4	LVTTL-O	Interrupt	Interrupt (bar); Indicates presence of an	2	
			important		
			condition which can be read over the		
			serial 2-wire		
			interface		
5	LVTTL-I	TX_DIS	Transmitter Disable; Transmitter laser		
			source turned off		
6		VCC5	+5 Power Supply-Not Required		
7		GND	Module Ground	1	
8		VCC3	+3.3V Power Supply		
9		VCC3	+3.3V Power Supply		
10	LVTTL-I	SCL	Serial 2-wire interface clock	2	
11	LVTTLI/O	SDA	Serial 2-wire interface data line	2	
12	LVTTL-O	Mod_Abs	Module Absent; Indicates module is not	2	
			present.		
			Grounded in the module		
13	LVTTL-O	Mod_NR	Module Not Ready	2	
14	LVTTL-O	RX_LOS	Receiver Loss of Signal indicator	2	
15		GND	Module Ground	1	
16		GND	Module Ground	1	
17	CML-O	RD-	Receiver inverted data output		
18	CML-O	RD+	Receiver non-inverted data output		
19		GND	Module Ground	1	
20		VCC2	+1.8V Power Supply – Not required		
21	LVTTL-I	P_Down/RST	Power Down; When high, places the		
			module in the low power stand-by mode		
			and on the falling edge of P_Down		



			initiates a module reset	
			Reset; The falling edge initiates a	
			complete reset of the module including	
			the 2-wire serial interface, equivalent to	
			a power cycle.	
22		VCC2	+1.8V Power Supply – Not required	
23		GND	Module Ground	1
24	PECL-I	RefCLK+	Reference Clock non-inverted input, AC	3
			coupled on the	
			host board – Not required	
25	PECL-I	RefCLK-	Reference Clock inverted input, AC	3
			coupled on the host board – Not required	
26		GND	Module Ground	1
27		GND	Module Ground	1
28	CML-I	TD-	Transmitter inverted data input	
29	CML-I	TD+	Transmitter non-inverted data input	
30		GND	Module Ground	1

Note:

- 1. Module circuit ground is isolated from module chassis ground within the module.
- 2. Open collector; should be pulled up with 4.7k 10k ohms on host board to a voltage between 3.15V and 3.6V.
- 3. A Reference Clock input is not required.

Host Board Connector Pinout






Table 6- General Specifications

parameter	Symbol	Min	Тур	Max	Units	Ref.
Bit Rate	BR	9.95		11.3	Gb/s	1
Bit Error Ratio	BER			10^{-12}		2
Max. Supported Link	LMAX		70		km	1
Length						

NOTE:

1. SONET OC-192 SR-1,SDH STM I-64.1 ,10GBASE-LR/LW, 1200-SM-LL-L

Tested with a 2^{23} - 1 PRBS


Digital Diagnostic Functions

FiberStore 's Small Form Factor 10Gb/s (XFP) transceivers are compliant with the current XFP Multi-Source Agreement (MSA) Specification Rev 4.5. As defined by the XFP MSA, FiberStore XFP transceivers provide digital diagnostic functions via a 2-wire serial interface, which allows real-time access to the following operating parameters:


- ♦ Transceiver temperature
- ♦ Laser bias current
- ♦ Transmitted optical power
- ♦ Received optical power
- ♦ Transceiver supply voltage

It also provides a sophisticated system of alarm and warning flags, which may be used to alert end-users when particular operating parameters are outside of a factory-set normal range. The operating and diagnostics information is monitored and reported by a Digital Diagnostics Transceiver Controller inside the transceiver, which is accessed through the 2-wire serial interface. When the serial protocol is activated, the serial clock signal (SCL pin) is generated by the host. The positive edge clocks data into the XFP transceiver into those segments of its memory map that are not write-protected. The negative edge clocks data from the XFP transceiver. The serial data signal (SDA pin) is bi-directional for serial data transfer. The host uses SDA in conjunction with SCL to mark the start and end of serial protocol activation. The memories are organized as a series of 8-bit data words that can be addressed individually or sequentially. The 2-wire serial interface provides sequential or random access to the 8 bit parameters, addressed from 000h to the maximum address of the memory.

Recommended Host Board Power Supply Circuit




Recommended High-speed Interface Circuit



Mechanical Specifications

FiberStore's XFP transceivers are compliant with the dimensions defined by the XFP Multi-Sourcing Agreement (MSA).





Ordering Information

Part No.	Data Rate (Gbps)	Wavelengt h (nm)	Connector Type	Transmission Distance (km)	Operating case temperature (°C)	Digital Diagnostics
XFP-10G55-40-xx	10	1550	LC	40	0 to +70	Yes

Notes:

xx means compatible brand. (For example: CO= Cisco, JU=Juniper, FD=Foundry, EX=Extreme, NE=Netgear, etc.)

FiberStore U.S.

X205 4181 129th Place SE, Bellevue

98006, WA,

United States

Tel: +1 (206) 453 0158

Fax: +1 (425) 505 2761

FiberStore Hong Kong

1220 Tung Chun Commercial Centre, 438-444 Shanghai Street, Kowloon,

HongKong

Tel: (852) 8120 3582

Fax: (852) 8120 3582

FiberStore China

5D Intelligent Tower, Fumin Road Futian,

Shenzhen 518045, GuangDong,

China

Tel: +86 (755) 8300 3611 Fax: +86 (755) 8326 9395

Addresses, phone number and fax number also have been listed at www.fiberstore.com. Please e-mail us at sales@fiberstore.com or call us for assistance.

All statements, technical information, and recommendations related to the products herein are based upon information believed to be reliable or accurate. However, the accuracy or completeness thereof is not guaranteed, and no responsibility is assumed for any inaccuracies. Please contact FiberStore for more information.